



Bob Timberlake Wood Burning 18 Inch Square Fire Pit with Lid



INSTRUCTIONS



SAFETY NOTICE: FOR YOUR SAFETY DO NOT INSTALL IN OR ON RECREATIONAL VEHICLES AND/OR IN BOATS.



NOTE: READ INSTRUCTIONS BEFORE USING YOUR FIRE PIT, USE EXTREME CAUTION AT ALL TIMES WHILE IN USE!



WARNING: FAILURE TO FOLLOW THE DANGERS, WARNING AND CAUTIONS CONTAINED IN THIS OWNERS MANUAL MAY RESULT IN SERIOUS BODILY INJURY OR DAMAGE TO PROPERTY



WARNING! CARBON MONOXIDE HAZARD! BURNING WOOD OR CHARCOAL PRODUCES CARBON MONOXIDE, WHICH HAS NO ODOR AND CAN KILL YOU IF BURNED IN ENCLOSED AREAS. NEVER BURN WOOD OR CHARCOAL INSIDE HOMES, VEHICLES, TENTS OR ANY OTHER ENCLOSED AREAS.

1.  **NEVER:** Start a fire with gasoline, kerosene, diesel fuel or any other petroleum-base accelerants!

2.  **DO NOT:** Burn on wood surface or any surface which is combustible or flammable! Check with your local municipality or fire district before using an out door wood burning fire pit!

3.  **DO NOT:** Use in doors! The Buck Stove fire pit is designed for outdoor use only! If used indoors, toxic fumes will accumulate and cause serious bodily injury or death!

4.  Your Buck Stove fire pit is hot while burning! Use **extreme caution** with children and pets when fire pit is burning!

5.  When using the Buck Stove fire pit exercise the same caution that you would with camp fire!

6.  **DO NOT:** Use your Buck Stove fire pit under, on and around any over head construction or low hanging branches, dry grass, brush piles, wood piles awnings, wood furniture, propane, flammable gasses or vapor, paper, compressed paper, plastic and plexiglass, or anything combustible.

7.  A minimum of **(4'-fourfoot)** must be maintained from any combustible materials while in operation. Follow local codes and specific safety instruction for your area.

8.  **DO NOT:** Operate your Buck Stove fire pit unless it is on level surface!

9.  **DO NOT:** Use your Buck Stove fire pit in a garage, building breezeway or any other enclosed area!

10.  Position your Buck Stove fire pit so that it is shielded from strong wind and gust!

11.  Your Buck Stove fire pit comes with tools to lift the lid or adjust it. You can also use it to stoke the fire. Its highly recommended to use heavy duty gloves when handling wood or the lid.

12.  **DO NOT:** Leave your Buck Stove fire pit unattended! Keep a fire extinguisher on hand when you have a fire going.

13.  **DO NOT:** Store the Buck Stove fire pit with combustible materials or ashes inside the fire pit.

14.  Make sure the fire pit is not in use and has cooled down, then use a cloth to remove the soot.

15.  For fire pits, screens are very important. Screens help catch flying embers or ashes when the wind blows, this keeps you, your guest and neighbors safe. We recommend use of fire screen at all times.

16.  Always start with small fires, this will help you gage how the fire will behave in your fire pit.

17.  **DO NOT:** Burn pressure treated wood in your Buck Stove fire pit. These items produces toxic gases that can be harmful.

18.  **DO NOT:** Move your Buck Stove fire pit while it is burning!


19.  Use caution when removing ashes and coals from fire pit, Dispose ashes in tight sealed metal container, use dirt or sand to smooth the ashes out.

INSTALLING BUCK STOVE FIRE PIT GRILL

- ◆ Locate the Buck Stove Fire Pit in an area that has **NO COMBUSTIBLES WITHIN (8') EIGHT FOOT SQUARE** area, with **NO COMBUSTIBLES OVER HEAD**.
- ◆ **NOTE: The manufacturer recommends that for maximum performance burn natural seasoned hard wood.** Remove the screen lid from the fire pit. Lay several pieces of dry kindling on top of newspaper, on wood grate. Place several pieces of natural seasoned hard wood or hickory wood on kindling. Light newspaper. Don't leave fire unattended at this point. After embers and a coal bed have been established, load fire pit with seasoned natural hard wood as desired for cooking. Place the Buck Stove Fire Pit Grill over the fire pit as shown in picture below, making sure bent part of placement brackets are inside fire pit. Your Buck Stove Fire Pit Grill is ready for use. Your fire pit cooking grill has an opening in the rear for adding additional wood fuel.

NOTE: Always keep safety in mind when disposing hot ashes. Pour water on them until out. Dig a hole and bury ashes, transport ashes using metal container with lid.

NOTE: For cleaning, remove cooking grate and remove fire shield. Clean fire shield, then replace fire shield, then cooking grate.





Limited Warranty

1 Year Limited Warranty

TERMS OF YOUR LIMITED WARRANTY: Manufacturer warrants to the original purchaser of product, and to no other person, that if this product is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such product shall be free from defects in material and workmanship. Manufacturer may require reasonable proof of your date of purchase. Therefore, purchaser should retain sales receipt or invoice. This Limited Warranty shall be limited to the repair or replacement of parts, which prove defective under normal use and service and which Manufacturer shall determine in its reasonable discretion upon examination to be defective. Before returning any parts, Manufacturer should be contacted. If defective parts are returned, transportation charges must be prepaid by customer. Manufacturer will return replacement parts to the original retail purchaser, freight or postage paid.

This Limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the product as set out in the owner manual. In addition, the Limited Warranty does not cover the damage to the finish, such as scratches, dents, discoloration, rust or other weather damage, after purchase.

To be completed by selling distributor/ dealer/ customer:

Email: info@buckstove.com

Name _____
(Last) (First)

Address _____

City _____ State _____ Zip _____

MODEL **RDFP 18** **SDFP 18** **RDFP 30**

Date Purchased: Month _____ Year _____